

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially if children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING

DO NOT IMMERSE IN WATER DANGER —

To reduce the risk of electric shock:

1. Always unplug this appliance immediately after using.
2. Never use while bathing or in the shower. Use only in a dry area.
3. Never place or store the appliance where it can fall or be pulled into a tub or sink.
4. Do not place or drop into water or other liquids.
5. Never reach for an appliance that has fallen into water. Unplug immediately.

WARNING

To reduce the risk of burns, electrocution, fire or injury to persons:

1. Never leave the appliance unattended when plugged in.
2. This appliance should not be used by, on,

or near children or individuals with certain disabilities.

3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Satin Smooth™.

4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return it to a service center for examination and repair.

5. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and other debris.

6. Never use while sleeping or drowsy.
7. Never insert any object into any opening.
8. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
9. Do not use an extension cord with this appliance.

10. For best results, use Satin Smooth™ wax.
11. Do not apply hot wax near eyes or other heat-sensitive areas, or to any skin injury, eruption, or surface growth.
12. Do not touch hot surfaces. Allow the appliance to cool before handling, cleaning or storing.
13. Place the appliance on a level surface.
14. Do not let cord hang over edge of table

or counter where it can be pulled on by children or tripped over unintentionally.

15. Always unplug the unit from the electrical outlet immediately after using and before cleaning.

16. Ensure that your hands are dry when operating the controls, plugging in or unplugging the unit.

17. The physiological effects of this appliance have not been evaluated by ETL SEMKO.

18. Always test hot wax on a small area of skin for temperature and possible skin reactions before starting treatment. It is recommended that individuals susceptible to allergic reactions or suffering from circulatory problems consult a physician before waxing.

19. Keep out of reach of children.

CAUTIONS

1. Clients should consult their physician prior to waxing in case of illness or medical condition, including but not limited to pacemaker use, pregnancy, cancer, infection, fracture, persistent or unexplained pain, swollen muscles or serious injury.
2. Do not wax if client suffers from any of the following conditions: diabetes, tuberculosis, benign or malignant tumor, phlebitis, thrombosis, hemorrhages, open or fresh wounds, ulcerated sores, varicose veins, poor circulation or bruised, discolored, burned, broken, swollen or inflamed skin.
3. Do not wax if client suffers from a

condition that limits or altogether inhibits his/her capacity to feel or have sensation in any part of the body.

4. Discontinue treatment if waxing causes pain or swelling.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

This appliance is intended for professional use only. Use on alternating current (60 Hertz) only. This appliance is designed to operate at 125V AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

DIRECTIONS FOR USE

Read complete directions before use and follow instructions carefully. Save these instructions for future reference.

1. Remove the appliance from carton, and discard all packing materials. DO NOT TURN WARMER ON AT THIS TIME.
2. Remove any packaging material from inside of warmer.
3. Remove the wax container cover.

4. Place wax container into the warmer well. IMPORTANT: DO NOT POUR WAX DIRECTLY INTO WARMER WELL.

5. Plug cord into electrical outlet.

6. Turn the warmer switch to the ON position. The red light will appear, indicating that the unit is on.

7. Set the temperature dial to HOT. This will produce a rapid heat-up and melt the wax quickly. Note: Heat-up time may vary depending on the type of wax being used, the temperature of the wax prior to warming and the size of the wax container. Allow 25–30 minutes to melt a 14 oz. can of solid wax.

8. Once the wax is melted, set the temperature to READY and allow 20–30 minutes for the wax to stabilize to a usable temperature.

9. Wax temperature should be comfortable to use on skin. Never apply wax to the skin from the HOT temperature setting. Always test the temperature of the wax on the inside of your wrist before waxing.

STIR THE WAX REGULARLY AND THOROUGHLY DURING HEAT-UP AND BEFORE USE TO ENSURE EVEN TEMPERATURE AND UNIFORM CONSISTENCY.

TO RELEASE LID:




Hold the unit firmly with one hand. Pull the lid in the direction of the arrow with the other hand.

TO INSERT LID:



Insert one end into the hinge.



Insert the other end into the other hinge.



Use your thumb to press the second end into the hinge



Done.

WAXING

1. For best results, hair should be at least ¼" long. Do not use cream or body lotion before waxing.
2. Ensure that skin is clean and dry. Skin may be cleaned using Satin Cleanser® Skin Preparation Cleanser. ALWAYS TEST A SMALL AMOUNT OF WAX FOR TEMPERATURE ON THE INSIDE OF YOUR WRIST BEFORE APPLICATION BEGINS.

3. USE VERY LITTLE WAX EACH TIME. Scrape off the excess on the edge of the pot, leaving only a thin film on the spatula.
4. Apply the wax with spatula tilted at an angle, spreading very thinly over an area slightly less than the size of the wax strip being used.

5. When waxing legs, use spatula to spread the wax thinly over the area to be treated, applying in the direction of hair growth. Only apply the wax to one small area at a time.

6. Hair on the bikini line or under the arms is stronger and thicker. Trim the hair with a trimmer before applying the wax. TAKE CARE NOT TO GO TOO CLOSE TO THE MORE SENSITIVE AREAS.

7. Treat smaller areas with less wax than on the legs and reduce the size of the strips to suit the size of the area being treated.

8. Place one strip over the waxed area and press down firmly with the palm of your hand, exerting an even pressure over

the whole strip. Hold the skin taut and peel the strip sharply away in one quick movement, against the direction of hair growth.

9. Should any hair remain, reapply the same wax-coated strip and remove as described in Step #8. Repeat until the entire area being treated is free from hair. If some wax remains on the skin, remove using Satin Release® Wax Residue Remover.
10. Having finished a section [e.g., half a leg], apply Satin Hydrate® Skin Nourisher evenly over the area and smooth in.

To obtain best results, once a regular waxing routine has been established with your client, wax applications should be repeated every 4–6 weeks, depending on the rate of hair growth.

PLEASE NOTE THAT THE WAX SHOULD BE STIRRED REGULARLY AND THOROUGHLY DURING HEAT-UP PROCESS AND AGAIN BEFORE USE. THIS IS TO ENSURE THAT THE TEMPERATURE AND CONSISTENCY OF THE WAX ARE EVEN THROUGHOUT.

AFTER WAXING

After waxing, turn the warmer switch to the OFF position and unplug from the power source. Remove the wax pot from the warmer and clean both the heater and the outer surface of the wax container with Satin Release®. The

partially used wax container can be stored in the warmer, with the warming unit cover in place to protect from dust and foreign elements.

USER MAINTENANCE

Your warmer is easy to maintain. Proper maintenance will assure dependable service and a clean appearance.

1. Always unplug unit after using and allow it to cool before cleaning.
2. Wipe exterior with a damp cloth, Satin Release® Wax Residue Remover or Re Movelt Surface Cleaner.
3. If any abnormal conditions occur, unplug the unit, allow it to cool and return it to an authorized service center for repair.

STORAGE

Allow the appliance to cool before storing. Handle cord carefully to prolong its life; avoid jerking or straining at plug connection. Keep appliance in a safe, dry location, out of reach of children.

WARNING: IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.

KEEP AWAY FROM WATER

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

Thank you for choosing Satin Smooth™ Professional Single Wax Warmer. Thanks to this product and Satin Smooth™ waxes, your clients' skin will always feel soft and silky. Satin Smooth™ Professional Waxing System is the complete answer to hair removal.

This warmer was built with advanced engineering and a thermostatically controlled heating element that delivers high quality, consistent results. Its unique and upscale design will complement any professional environment.

You can be assured that the Satin Smooth™ Professional Single Wax Warmer will provide you with long and dependable service, allowing you to concentrate on your clients' needs.

IF YOU LIVE OUTSIDE CANADA, PLEASE CONTACT YOUR LOCAL DISTRIBUTOR.

CANADIAN ONE YEAR REPLACEMENT WARRANTY

Dannycos Professional is the exclusive Canadian distributor of this product. We offer the following excellent warranty on your professional electrical appliance. Keep your sales slip. This is your proof of purchase and your guarantee. This guarantee is not valid in case of abuse, misuse, alterations or repairs done by unauthorized persons. Before returning your defective electrical product, please read the warranty conditions listed in this brochure.

Should your professional electrical appliance possess a manufacturer's defect, it may be exchanged by your distributor or Dannycos Professional at no charge within ONE YEAR from date of purchase, if the electrical appliance is accompanied by a proof of purchase.

If you are sending your defective appliance which is covered by this guarantee, directly to the Dannycos Professional Service Center; it must be accompanied by the following:

- 1) your dated sales slip;
- 2) a precise description of the defect;
- 3) your complete return address and daytime phone number; and,
- 4) a \$10 money order for postage and handling

Please return your defective appliance to:

ATTN: Dannycos Professional Service Center
CONAIR CONSUMER PRODUCTS ULC
100 Conair Parkway
Woodbridge, Ontario
L4H 0L2

This warranty applies only to residents of Canada. Products shipped from outside of Canada will not be processed and will not be returned to sender.

For questions regarding this product, you may call Dannycos Professional's Service Centre at:

1-800-363-0707, or email us at customerservice@dannycos.com.



SATIN SMOOTH™

Afin que votre appareil vous procure en toute sécurité beaucoup satisfaction, lisez toujours soigneusement le livret de directives avant de l'utiliser.

Chauffe-cire professionnel

Modèle SSW12CC

Pour usage professionnel uniquement

IB-14/358A

IMPORTANTES CONSIGNES DE SÉCURITÉ

L'utilisation d'appareils électriques, notamment en présence d'enfants, requiert la prise de précautions élémentaires, parmi lesquelles les suivantes:

LIRE TOUTES LES INSTRUCTIONS AVANT D'UTILISER L'APPAREIL

GARDER LOIN DE L'EAU

DANGER —

Afin de réduire le risque de choc électrique :

1. Toujours débrancher l'appareil après l'avoir utilisé.
 2. Ne pas utiliser dans le bain ou la douche. Utiliser uniquement dans un endroit sec.
 3. Ne pas laisser l'appareil dans un endroit où il peut tomber ou être entraîné dans une baignoire ou un lavabo.
 4. Ne pas placer ou laisser tomber dans l'eau ou tout autre liquide.
 5. Ne jamais tenter de rattraper l'appareil s'il tombe dans l'eau. Le débrancher immédiatement.
- ### AVERTISSEMENT
- Afin de réduire le risque de brûlures,

d'électrocution, d'incendie ou de blessures:

1. Ne pas laisser l'appareil sans surveillance pendant qu'il est branché.
2. Cet appareil ne devrait pas être utilisé par, sur ou près d'enfants ou de personnes souffrant d'un certain handicap.
3. Utiliser aux fins indiquées dans ce manuel uniquement. Utiliser uniquement les accessoires recommandés par le fabricant.
4. Ne pas utiliser l'appareil si le cordon d'alimentation ou la fiche sont endommagés, s'il ne fonctionne pas correctement, s'il est tombé, s'il est abîmé ou s'il est tombé dans l'eau. Le renvoyer à un service après-vente autorisé afin qu'il soit inspecté et réparé.
5. Ne pas obstruer les ouvertures ou placer l'appareil sur une surface molle telle qu'un lit ou un divan, où elles pourraient se boucher. Vérifier que les entrées d'air ne sont pas obstruées par des peluches, cheveux ou autres débris.
6. Ne pas utiliser l'appareil en dormant ou somnolant.
7. Ne pas introduire ou laisser tomber d'objets dans les ouvertures.
8. Ne pas utiliser à l'air libre ou dans des endroits où l'on utilise des produits aérosols (spray) ou où l'on administre de l'oxygène.
9. Ne pas utiliser avec une rallonge électrique.
10. Pour un résultat optimal, utiliser la cire Satin Smooth™.

demande l'avis de leur docteur avant le traitement.

11. Ne pas appliquer de cire chaude près des yeux, sur les zones sensibles ou sur les lésions, éruptions ou excroissances cutanées.
12. Ne pas toucher les surfaces chaudes. Laisser l'appareil refroidir avant toute manipulation ou entretien.
13. Placer l'appareil sur une surface plate.
14. Ne pas laisser le cordon pendre du comptoir ou de la table. Un enfant pourrait le tirer ou trébucher dessus par inadvertance.
15. Débrancher après usage et avant toute manipulation ou entretien.
16. Ne jamais brancher ou débrancher le cordon avec les mains mouillées.
17. ETL SEMKO n'a pas évalué les effets physiologiques de cet appareil.
18. Toujours tester la cire sur une petite zone de peau avant de procéder à l'épilation pour vérifier sa température et s'assurer qu'il n'y a pas de réaction cutanée. Les personnes prédisposées aux réactions allergiques ou souffrant de problèmes circulatoires devraient consulter un médecin avant l'épilation.
19. Garder hors de portée des enfants.

MISES EN GARDE

1. Votre client(e) devrait demander l'avis de son médecin traitant avant l'épilation s'il ou elle a un stimulateur cardiaque, souffre d'un cancer, d'une infection, d'une fracture, de douleurs persistantes ou inexplicables, d'enflure ou d'une blessure sérieuse. Les femmes enceintes devraient également

demande l'avis de leur docteur avant le traitement.

2. Ne pas procéder à l'épilation si votre client(e) souffre de diabète, tuberculose, tumeur bénigne ou maligne, phlébite, thrombose, hémorragie ou varice ou si la peau présente une blessure récente, plaie, infection, irritation, coupure, ecchymose, brûlure, coup de soleil ou autre.
3. Ne pas procéder à l'épilation si votre client(e) souffre d'une condition rendant sa peau partiellement ou complètement insensible.
4. Interrompre l'épilation en cas de douleur ou enflure.

PRÉPARATION

Lire attentivement le mode d'emploi avant d'utiliser l'appareil. Le conserver pour référence ultérieure.

1. Sortir l'appareil de la boîte et jeter le matériel d'emballage. NE PAS METTRE L'APPAREIL EN MARCHÉ.
2. Retirer le matériel d'emballage qui se trouve à l'intérieur de la cuve.
3. Ouvrir le pot de cire.
4. Mettre le pot de cire dans la cuve.
5. Brancher l'appareil.
6. Appuyer sur l'interrupteur pour mettre l'appareil en marche. Le voyant de mise sous tension s'allumera.
7. Régler la température au niveau maximum (HOT) afin de faire fondre la cire rapidement. Remarque : Le temps de fonte de la cire dépendra du type de cire utilisée, de sa température initiale et de la quantité de cire dans le pot. Un pot de cire de 14 onces (400 g) fondra en 25–30 minutes.
8. Une fois la cire fondue, régler la température au niveau désiré (généralement READY) puis attendre 20–30 minutes, jusqu'à ce que la température se stabilise.
9. La température de la cire devrait être confortable. Ne jamais appliquer jamais la cire alors que la température est au niveau maximum. Toujours tester la température de la cire sur votre poignet avant de commencer l'épilation.

MÉLANGER FRÉQUEMENT LA CIRE PENDANT LA FONTE ET AVANT L'UTILISATION POUR GARANTIR UNE CONSISTANCE HOMOGÈNE ET UNE TEMPÉRATURE UNIFORME.

POUR RETIRER LE COUVERCLE :




Tenir l'appareil fermement avec une main. Tirer sur le couvercle dans le sens de la flèche avec l'autre main.

POUR INSTALLER LE COUVERCLE :



Introduire l'autre côté dans l'autre charnière.



Et voilà !

ÉPILATION

1. Pour un résultat optimal, les poils devraient mesurer au moins 5 mm. Ne pas appliquer de crème ou de lotion pour le corps avant l'épilation.
2. La peau devrait être propre et sèche. Nettoyer la peau à l'aide du nettoyant pré-dépilatoire Satin Cleanser® au besoin. TOUJOURS TESTER LA TEMPÉRATURE DE LA CIRE SUR VOTRE POIGNET AVANT DE COMMENCER L'ÉPILATION.
3. UTILISER LE MOINS DE CIRE POSSIBLE. Racler un côté de la spatule sur le rebord du pot de cire, de façon à ne laisser qu'une mince pellicule de cire sur la spatule.
4. Incliner légèrement la spatule et étaler une couche de cire très mince sur la zone à épiler, dans le sens de la pousse des poils. La couche de cire devrait être légèrement plus étroite que la bande d'épilation utilisée.

5. Pour épiler les jambes, appliquer la cire sur de petites zones au lieu de sur la jambe entière.
6. Les poils du maillot et des aisselles sont épais et résistants. Il est conseillé de les tailler au préalable pour faciliter l'épilation. VEILLER À NE PAS APPLIQUER DE CIRE SUR LES RÉGIONS SENSIBLES.

DIRECTIVES ENTRETIEN

Votre appareil demande peu d'entretien. Il suffit de le nettoyer régulièrement pour garantir son bon fonctionnement et sa propreté.

1. Toujours débrancher l'appareil et le laisser refroidir avant de le nettoyer.
2. Nettoyer le boîtier de l'appareil avec un linge légèrement humide ou imbibé d'huile Satin Release® ou de nettoyant universel ReMoveIt.
3. En cas de problème, débrancher l'appareil, le laisser refroidir et le renvoyer à un service après-vente autorisé.

APRÈS L'ÉPILATION

Éteindre et débrancher l'appareil. Retirer le pot de cire et le nettoyer, ainsi que l'intérieur de la cuve, à l'aide de Satin Release®. Vous pouvez laisser le pot de cire entamé dans l'appareil si vous le souhaitez. Refermez simplement le couvercle de l'appareil pour protéger la cire.

DIRECTIVES ENTRETIEN

Votre appareil demande peu d'entretien. Il suffit de le nettoyer régulièrement pour garantir son bon fonctionnement et sa propreté.

1. Toujours débrancher l'appareil et le laisser refroidir avant de le nettoyer.
2. Nettoyer le boîtier de l'appareil avec un linge légèrement humide ou imbibé d'huile Satin Release® ou de nettoyant universel ReMoveIt.
3. En cas de problème, débrancher l'appareil, le laisser refroidir et le renvoyer à un service après-vente autorisé.

AVERTISSEMENT : SI VOUS PENSEZ QUE LE COURANT EST COUPÉ PARCE QUE L'APPAREIL EST ÉTEINT, VOUS VOUS TROMPEZ.

GARDER LOIN DE L'EAU

Tout le monde sait que l'eau et l'électricité ne font pas bon ménage, mais saviez-vous qu'un appareil est toujours sous tension, même lorsqu'il est éteint? S'il est branché, il est sous tension. Alors, si vous n'utilisez pas l'appareil, débranchez-le.

DÉBRANCHEZ TOUJOURS LES PETITS APPAREILS ÉLECTRIQUES

Merci d'avoir choisi le chauffe-cire professionnel Satin Smooth™. Grâce à cet appareil et à la cire Satin Smooth™, la peau de vos clientes sera toujours douce et satinée. Satin Smooth™ offre la solution à tous les problèmes de poils disgracieux. Ce chauffe-cire est un appareil de pointe, équipé d'une résistance à commode thermostatique offrant des résultats supérieurs. Élegant, il complimentera parfaitement tout décor professionnel. Satin Smooth™ vous permet de vous concentrer sur les besoins de vos clients, sans avoir à vous soucier de la fiabilité de votre chauffe-cire.

SI VOUS RÉSIDEZ À L'EXTÉRIEUR DU CANADA, VEUILLEZ COMMUNIQUER AVEC VOTRE DISTRIBUTEUR LOCAL.

GARANTIE DE REPLACEMENT CANADIENNE D'UN AN


Dannyco Professionnel est le distributeur canadien exclusif de cet appareil électrique professionnel. Nous offrons la garantie exceptionnelle suivante sur votre appareil électrique professionnel. Conservez votre reçu de caisse, car c'est votre preuve d'achat et votre garantie. Cette garantie n'est pas valide si des personnes non autorisées ont fait un mauvais usage de l'appareil, ont tenté de le modifier ou de le réparer. Avant de retourner l'appareil électrique défectueux, veuillez lire les conditions de garantie inscrites à l'intérieur de ce dépliant. Si votre appareil électrique professionnel présente un défaut de fabrication à l'intérieur D'UN AN suivant la date d'achat, vous pouvez l'échanger sans frais en le retournant à votre distributeur ou directement à Dannyco Professionnel, s'il est accompagné d'une preuve d'achat. Si vous retournez l'appareil défectueux toujours sous garantie directement à Dannyco Professionnel, il doit être accompagné :
1) de votre reçu de caisse daté;
2) d'une description précise du problème;
3) de votre adresse de retour complète et votre numéro de téléphone de jour; et

- 4) d'un mandat-poste de 10 \$ pour couvrir les frais de port et de manutention

Veuillez retourner l'appareil défectueux à:
ATT. : Centre De Service Dannyco Professionnel
CONAIR CONSUMER PRODUCTS ULC
100 Conair Parkway
Woodbridge, Ontario
L4H 0L2

Cette garantie s'applique uniquement aux résidents canadiens. Nous ne traiterons pas les produits provenant de l'extérieur du Canada et ne les retournerons pas à l'expéditeur.

Si vous avez des questions concernant ce produit, communiquez avec le centre de service Dannyco Professionnel au:
1-800-363-0707 ou écrivez à customerservice@dannyco.com.



For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Professional Single Wax Warmer

Model SSW12CC
For Professional Use Only

IB-14/358A